

Quick Start redKnows MiniFinder – get going right away!

All that you need to get going with MiniFinder is a SIM card. With a prepaid card you avoid subscription costs. Before you activate the alarm, make sure that: a) the SIM card has Caller ID, b) mobile phone voicemail is disconnected, and c) the PIN number is removed. You should register the card with the operator. Make sure that the card is loaded with money.

SIM card is inserted with the clipped corner to the left.
NOTE! The alarm should always be **TURNED OFF** if SIM card is taken out or inserted into the alarm.



1. Make sure that the alarm is turned off! Insert the SIM card – with the cut-off corner to the left.
2. Start MiniFinder by moving the switch from 0=OFF to 1=ON. The start-up can take up to 30 seconds. Wait until the green LED diode is lit.
3. The alarm searches the position for about 2 minutes. This is NOT indicated by any diode. Make sure MiniFinder has a clear view of the sky.
4. Call MiniFinder's mobile phone number from any mobile phone. You will hear a signal, after which you will be disconnected. Within a few minutes you will receive an SMS text message with the date, time (GMT), position and a link that opens a map where the alarm's position is shown (requires access to the Internet or WAP).
5. Do not forget to charge the internal battery as soon as possible or to connect to an external power source.
 - With 230V charger. If MiniFinder is turned off during charging, the LEDs blink red, yellow and green when charging is taking place. When charging is finished, the blinking changes to red and green. Always charge MiniFinder for at least 4 hours the first time!
 - With a 12V cigarette lighter outlet (accessory).
 - Connect to an external power source, 6-30V DC, with the accompanying cable. Red is plus(+), black minus(-). If the charging is to occur continuously, cut off the narrower portion of the wide cableport to the cover and insert the charging cable through the cover. Be careful!

NOTE! Before you programme MiniFinder at www.redknows.se, all mobile phones with access to the SIM card's number can call MiniFinder and track the alarm. Nor are any alarm functions activated in this case!

Activate other functions:

6. Register your MiniFinder at our home page www.redknows.se under **EZ-Start MiniFinder**. There you should determine which mobile phone numbers will be able to make contact with your alarm. Until you do this, any one with access to MiniFinder's number can call the alarm and track it through their mobile phone. Create an account and activate the functions:
 - Geofence (movement alarm)
 - Vibration alarm
 - SOS (emergency SMS)

You then can easily activate/deactivate these functions with the aid of SMS (see manual) and remote control:

Press GEO – red LED on MiniFinder blinks while searching position. Steady red light for 1 min. when position is found and Geofence is active.

Press STANDBY – green LED on MiniFinder shines with steady light for 1 min. In this case only tracking of the alarm is active. Standby deactivates Geo and VIB.



Press VIB – yellow LED on MiniFinder shines with steady light for 1 min. – vibration alarm is then active.

Press SOS – Keep SOS-button depressed for 5 seconds. SMS is sent to mobile phone number entered on web page.

For more detailed information – see MiniFinder users manual!